



GoPro MAX Replacement Lens Caps

248848

Replacement caps to protect the lenses of your MAX from dirt, dust and scratches when not in use. Or leave just one cap on when shooting in HERO mode.



PRODUCT DETAILS

Replace your MAX lens caps if they're damaged or lost. Designed to protect your camera lenses from dirt, dust and scratches when not in use. Also great for protecting the non-shooting lens when capturing in HERO mode.

Features

- Replacement lens caps for MAX
- Protect the lenses of your MAX when not in use, or protect your non-shooting lens when capturing in HERO mode
- Includes two MAX Replacement Lens Caps

Specs

Product Attributes

EAN:	0818279024074
Manufacturer number:	ACCPS-001
Product weight:	0.01 kilograms
Pieces per master carton:	1 Piece

Technical Specifications

Compatible models:	MAX
--------------------	-----